

TECHNICAL BULLETIN

TECHNICAL BULLETIN #140

SUBJECT: Omission from Second Stage Cleaning

Section of Warrior Operation Manual

DATE: January 24, 2012

PRODUCTS AFFECTED: All Warrior SCBAs

This Technical Bulletin addresses an omission from the Second Stage Regulator Cleaning section (pages 30-31) of the Warrior Operation Manual.

The Warning at the top of the right-hand column of page 30 is as follows:

A WARNING - Continued

It may be partially submerged only as instructed in step 8 below. Failure to comply with this Warning may lead to personal injury, illness, or death.

However, step 8 does not appear after step 7 on page 31. The information was unintentionally omitted when the Warrior Operation Manual was published.

The following is what should appear as step 8:

- 8. If dirt or debris interferes with the First-Breath-On mechanism, clean it as follows:
 - a. Remove the two Phillips screws that secure the rubber manual override button cover to the second stage regulator.
 - b. Remove the two plastic retainers from which you removed the screws.
 - c. Lift off the rubber manual override button cover.

- d. Place the protective cleaning cap over the outlet tube.
- e. Hold the regulator with the cover facing downward and rinse in a shallow bucket of fresh water.
- f. Allow the water to drain, and dry with low pressure Grade D air (15 psig maximum) directed into the venting groove under the shutoff button.
- g. Reinstall the rubber manual override button cover.
- h. Reinstall the two plastic retainers.
- i. Reinstall the two Phillips screws.

Please insert this step into your Warrior Operation Manual. It will be included in the next printing of the manual.